


# Cox Box<sup>®</sup> Panel Protector Installation Instructions

1.

Remove the wraparound protective bumper from the Cox Box.



2.

Clean the bonding surface with soap and water. Rinse and dry thoroughly.



3.

Clean the surface of the plugs and the surrounding panel space with the alcohol wipe.



4.

If rubber plugs are twisted, use microphone or charger socket to carefully rotate the plugs until they are straight.

More Steps ->

5.

After the alcohol has dried, remove the plastic film covering the adhesive tape on the bottom of the panel protector.



6.

Install the panel protector by aligning the straight edge of the panel with the bottom edge of the display screen.



7.

Add weight (such as a hard-bound book) on top of the panel protector to secure the adhesive bond.



8.

Wait 24 hours before use.

Visit [www.nkhome.com/support](http://www.nkhome.com/support) for more information.