# **Loudspeaker 2 Installation Instructions**

#### 0207S - Surface Mount Option:

- Clean location on boat where the speaker will be mounted to ensure there is no debris or contaminants present.
- Make sure this area dries completely before proceeding.
- Peel off plastic on back of speaker to expose adhesive. 3.
- Firmly press the back of the speaker against the boat to mount the speaker. 4.
- Hold speaker in place for at least 30 seconds to affix speaker to the boat.

#### 0207F - Footstretcher Mount Option:





- Acquire foot stretcher hardware (not provided): wing nut - typically 1/4 20 in size, washer/lock washer.
- Identify where on the foot stretcher you want to mount the speaker.
- Use hardware to attach speaker to foot stretcher. Bend bracket to desired angle for better acoustic positioning.

### 0207B - Bulkhead Mounting Option:



d, h, i not shown

## **WARNING!**

Please use adequate protection when performing this installation. Fiberglass can be very sharp and hazardous if inhaled or exposed to your eyes. We recommend using gloves, eye protection and nose and mouth protection before proceeding.

1. Connect the hole saw (a) to arbor (b). Then attach to drill (c).

3. Drill out center hole in template using a

in template using drill bit.

hole saw. Next drill out the 4 screw holes





2. Peel off plastic on back of provided template. Attach template to bulkhead where speaker will be mounted.



- a. Hole Saw (size 2 5/8", 67mm) (composite hole recommended)
- b. Arbor
- c. Drill
- d. Drill Bit: 5mm or 3/16" recommended
- e. Phillips Head Screwdriver
- f. Speaker
- g. Screws (4)
- h. PPE for eyes, mouth, nose
- i. Gloves.







- Remove screws (g) from speaker (f) and detach the back ring.
- Insert the body of the speaker into the hole.
- 6. Insert back ring of the speaker through the opening of the bulkhead and line it up with the screw holes.

Note: Ensure that the speaker wire goes through center of the back ring.

7. Tighten screws until the speaker is flush.



