

GPS Model 1 or 2 Heart Rate Belt Showing Either Erratic Readings or “---”

Symptoms: Heart rate belt shows very high/low numbers, HR belt shows “- - -” when paired, or HR belt erratically unpairing.

Solution: Corrosion build-up on the buckle contacts can cause these issues. Periodic cleaning of the buckle contacts will resolve the issue.

What you'll need:

- 1) Isopropyl Alcohol
 - 2) Foam swab or Q-Tip® or small brush.
- Note: Q-Tip® may be slightly too big for the Model 2 buckles.



Procedure:

Step 1: Spray the metal contacts with alcohol, both female and male ends. Or apply alcohol to cleaning tool.

Step 2: Using the cleaning tool available, rub the inside sockets of the belt and the “pins” of the buckle completely. Repeat for all the connections highlighted in Step 1.

